

Hirschmann Plug - Female

Specialty Venetian Blinds



Product	Type	Items
SVB	All types	Hirschmann plug - female

Connection Instruction

This plug is wired to supply connection to male plug fitted to motors.

Use only **ROUND** four core flexible cord so that waterproof seal is achieved in cable gland.

Remove 25 mm of outer sheath on flexible cord and clamp securely within plug.

Electrical requirements

All electrical work **MUST** be carried out by a licensed electrician in accordance with AS300 and any other statutory regulations that may be applicable.

See diagram below for connection example to a venetian blind motor. Please note Blue is NEUTRAL.

Switches, push buttons (light switches) or circuits, which simultaneously permit up and down commands, must not be connected.

When changing direction the drive must first be without power for at least 0.5 seconds.

Reverse operation

Should motor operate reverse to that required, simply reverse brown and black wires at switch point **ONLY**.

Warning

DO NOT connect 2 or more motors in parallel.

Motors will malfunction, causing possible damage to limit switches.

Introduction date

01 September 2012

